

VT-ACCU Rechargeable Backup Battery keeps the device operational while the main power source drops. While in operation, the batteries are charged. If the main power input voltage drops, the unit will work from VT-ACCU rechargeable batteries until the batteries are discharged.

VT-ACCU extension is used for VT825t, and VT855t Monitoring systems and VT604t, VT608t power distribution units.

Rechargeable batteries are not included.



